TALLATION INFORMATION

SHALLOW WOOFER SYSTEM

Our most popular size from the Shallow Woofer line is the SWS-8" due to the fact that it is designed to replace the BMW factory speakers that are located under the front seats. They are the best solution for replacing BMW subwoofers with hardly any modification required. Simply remove the seats and replace the factory woofers with the exact-fitting SWS-8 woofers to improve the sound quality of your mobile audio.

Earthquake Sound also produces the SWS-8Xi that has a 2Ω voice coil which is the same impedance as the BMW factory speakers.

In addition to BMW cars, the SWS series are used in many other applications where subwoofers are needed and space is limited, such as in car doors. Many car manufacturers are now using woofers in small areas. To improve your bass, simply replace the factory speakers with SWS woofers.







Attaching foam insulation to the edges of your SWS 8 inch driver is recommended before dropping it into the box. This prevents any air leaks.





This is the box with the factory sub removed, ready for the SWS shallow woofer.





The standard box under the BMW seat fits Earthquake's SWS 8 inch shallow woofer easily and with hardly any modification.